

# Sound

## SOUND

### Mixer:

Sound  
Devices MixPre (2 ch Stereo EB-Mixer)

### Sound Recorders:

ZOOM F6 (digital 6 ch 32bit floating point recorder for SD cards)

ZOOM  
H4N (digital recorder for SD cards with built in stereo  
Mic)

(incl. XLR line input to JACK mic output adapter cable (needed to use  
the ZOOM H4N in combination with the MixPre + external battery adapter +  
USB cable + 8GB SD card + protective dPF leathercase)

### Microphones:

Sennheiser MKH 418 S P48  
(Ms Stereo Mic.)

Sennheiser ME66 (with K6 or K6P  
module)

SHURE Lavalier microphone MicroFlex 183

TRAM TR50 Lavalier (modified for Sony transmitter)

SONY UHF SYNTHESIZED TRANSMITTER WRT-882B/62 (798.025-822.000 MHz)

+

SONY UHF SYNTHESIZED TUNER UNIT WRR-855A (800.125-814.000 MHz)

+

SONY Portable Tuner Mount Adapter BTA-801

Supports:

Quickpole Light Boom QXS 650 (Length: 65 &ndash; 260 cm (2.13 ft &ndash; 8.53 ft) Weight: 535 g )

Cables/Adapters:

XLR line input to JACK mic output  
adapter cable (needed to use the ZOOM H4N in combination with the  
MixPre / 2 available)

various cables available